



67 Series Installation Instructions

Fit lock/latch as per fitting instructions, with a 22mm spindle hole to allow for rotor clearance.

It is very important that holes are drilled squarely. Failure to do so will lead to difficulty in lining up the tapped holes in the rose. The following method is recommended:

- A** Place the rose with countersink holes on the lock spindle of the internal side of the door. Make sure the handle is sitting correctly and spot through the two screw holes onto the door.
- B** Use the same rose and place as illustrated below to spot screw holes on the external side of the door.
- C** Drill 6.5mm holes half way through the door and repeat on the other side of the door with the holes meeting in the middle of the door.
- D** To avoid cutting the screws too short, fit screws through the countersunk rose and the door, leaving 5mm protruding for fixing.

