

DOOR PULL

Drilling Template

FOR:
DP1.SS, DP2.SS, DP3.SS

- 1 Decide on height of door.
- 2 Decide on backset (ie, distance from door edge to centre of handle).
- 3 Fold template using required backset.
- 4 Position on required height.
- 5 Mark hole positions (2 holes only).
- 6 Pilot drill 3mm holes through door.
- 7 Finish drill holes: 11mm Ø for DP1.SS and DP2.SS from either side of door to help prevent any splintering.

6mm Ø for DP3.SS from either side of door to help prevent any splintering.

- 304 grade stainless steel.
- High quality stainless steel fittings.
- Full fixing instructions included.
- Suitable for use on glass doors and wooden doors up to 50mm thick.
- Stainless grub screw fixing.
- Suits Sylvan roller bolt mortice lock, ref. S757 or S731 euro mortice lock.

NOTE: USE LONGER SCREWS FOR WOODEN DOORS

G.D. Rutter Limited
127 Diana Drive,
Glenfield, Auckland
PO Box 100-183 NSMC,
Auckland 0745
Phone: 09 444 5359
Facsimile: 09 444 3972

