



# EXPRESSION DOOR PULL

## Drilling Template

FOR:  
XP5, XP6, XP8 Oval, XP9 Round

- 1 Decide on height of door.
- 2 Decide on backset (i.e. distance from door edge to centre of handle).
- 3 Fold template using required backset.
- 4 Position on required height.
- 5 Mark the correct hole positions for the model you have purchased ie, either XP5, XP6, XP8 Oval or XP9 Round.  
**Note: XP6 for 900 and 1200 hole centres are 720mm B/C and 1020mm B/C (3 pillars).**
- 6 Mark hole positions (2 holes only).
- 7 Pilot drill 3mm holes through door.
- 8 Finish drill 10mm holes from either side of door to help prevent any splintering.

- 316 Grade Stainless Steel.
- High quality stainless steel fittings.
- Full fixing instructions included.
- Suitable for wooden doors up to 50mm thick.
- Stainless grub screw fixing.

G.D. Rutter Limited  
127 Diana Drive,  
Glenfield, Auckland  
PO Box 100-183 NSMC,  
Auckland 0745  
Phone: 09 444 5359  
Facsimile: 09 444 3972

