



# Verta Privacy Turn Installation Instructions

## Tools required

- Tape measure
- Soft pencil
- Level
- 6.5mm, 8mm & 24mm drill bits
- Power drill
- Philips screwdriver

Note:

Check door thickness first.


- For doors 35–40mm thick, use 20mm M4 screws (x2)
  - For doors 40–45mm thick, use 30mm M4 screws (x2)
  - Verta Privacy Turn can be through bolt (recommended) or face fixed (for use with mortice lock).
- Verta turn set can be face fixed with G6 screws (not included).

## Instruction steps

### 1. Prepare door (template attached)


If door is predrilled, go to step 2, otherwise follow the steps below:

- With a soft pencil, mark holes as per drawing
- Check alignment using a level
- Drill holes
- Mark the centre for the latch hole and drill  $\text{Ø}24 \text{ mm} \times 85 \text{ mm}$  deep



### 2. Install Bolt


- Insert bolt into hole. Trace around the face plate
- Chisel until faceplate fits flush with door face
- Drill 2 pilot holes for latch fixing screws
- Fasten with screws



### 3. Furniture installation

3a.


- Screw studs onto rose as shown
- Cut spindle to length and insert into furniture



3b.

- Align studs with drilled holes and mount external furniture to door
- Secure the internal turn with M4 screws
- Install rose caps so they are flush with door surface


3b.



#### 4. Prepare jamb & install strike

- Mark vertical and horizontal centreline on jamb, exactly opposite centre of latch
- Use strike plate as pattern for cut-out. Chisel until strike plate fits flush with jamb face
- Use strike plate as pattern, chisel or drill 15mm deep for bolt hole
- Drill 2 pilot holes for strike fixing screws
- Fasten with screws


4.



#### FACE FIXING INSTRUCTIONS (for mortice lock applications)


- Mark spindle hole and pilot holes as per template
- Check alignment using a level and drill holes
- Cut spindle to length and insert into furniture
- Secure furniture with G6 screws (not provided)
- Install rose caps so they are flush with door surface

Face Fixing



### Drilling template (through fixing)

Important: Double check dimensions if printing from an electronic version



### Drilling template (face fixing)

Important: Double check dimensions if printing from an electronic version

