Qube

Our Astron Series door furniture is perfect for the modern home.

Rose

- 7058......Lever Set

 7058D.....Dummy Lever

 7059......Passage Set

 7060......Privacy Set

 7085......Entrance Set

 7195......Privacy Set Integrated
- Lever Set Includes Levers only
- > Dummy Set Includes single Lever Handle and 1152 Dummy Mount
- Passage Set Includes Levers and 1131 Tubular Latch - 60mm backset
- > Privacy Set Includes Levers, 1131 Tubular Latch (60mm backset) and 7032 Privacy Bolt, Turn and Escape
- > Entrance Set Includes Levers, 1143 Euro Mortice Lock, 7020 Escutcheons and 1148 Euro Cylinder and Turn
- Integrated Privacy Set Includes Levers and 60mm backset Tubular Privacy Latch







Astron



Specs

- > Constructed from zinc alloy
- > Suits door thicknesses of 32–50mm
- For door thicknesses that exceed this, custom spindles and alternative fixings will need to be sourced
- > Suitable for interior and exterior use

Installation

- > 60mm backset (see diagram)
- > 25mm spindle hole
- > 6mm pilot holes at 3 and 9 o'clock positions
- > Passage Set installation shown



Qube

Astron





To view this handle style in each finish option, visit our website and enter any product code listed on page 1 of this document.

Care & Maintenance

Stocked Finishes

To protect your handles we suggest cleaning the surface of your hardware periodically with a warm soapy lightly dampened cloth to remove any build-up of dust and grime that may cause corrosion and affect the integrity of the finish. Then simply dry thoroughly with a clean, soft cloth. Minimum of monthly cleaning of door handles is recommended for both finish preservation and general hygiene.

Atmospheric conditions, salt deposits, acids, caustic agents, cement or dust on construction sites all have the potential to cause discolouration to the surface.

Please avoid using any metal polishes, abrasive cleaners, scorers or rough cloths that may damage or scratch the hardware and do not spray or immerse the hardware in liquid to clean.