

SYDM3109 digital door lock

commissioning

STEP 1



Take off the battery cover.
Install 4 x AA batteries provided. Make sure they are fitted correctly.

STEP 2



With the door open, push the (I) button located to the left of the three buttons, below the batteries.

STEP 3



Select a 6-12 digit code and enter on keypad.

STEP 4



Press (I) button again. Keypad will now display your code. This is displayed one number at a time.

STEP 5



Make sure the auto/manual button is standing out - this is the auto position.

STEP 6



Put battery cover back on and close the door. Test your code by entering code on the keypad, then press the * key. The latch will retract. Open the door by pulling down on the handle.

STEP 7



4 cards are supplied with the lock. To register cards, first push the (I) button, then present cards to the keypad, one by one. As each card is registered, a "beep" will sound, and a number will appear on the keypad.

STEP 8



When you are finished registering all cards, press the (I) button again. All cards are now registered to the lock. Close the door and swipe card on the keypad. The latch will retract. Open the door by pulling down on the handle.