



SS Rose Furniture

32MM - 45MM PRIVACY SET
32MM - 55MM PASSAGE SET
DOOR THICKNESS

INSTALLATION OF
PASSAGE AND
PRIVACY SETS

Passage and Privacy set installation (steps 10 - 21)

	<p>Stop Screw</p>	<p>Stop Screw</p>		<p>Privacy Hole Only</p>																
<p>PRIVACY SET (displayed) Parts and assembly</p>	<p>Handing the furniture is done by positioning the stop and screw in the correct location to suit the handing required.</p>	<p>Fixed lever is achieved by positioning the stop and screw in the location shown. To suit the handing required.</p>	<p>Position lever assembly (side with nut insert) so that it operates downward to retract the latch bolt.</p>	<p>Align spindle into the square opening in latch, screws pass through screw holes.</p>																
		<p>Emergency access hole</p>																		
<p>Lightly tighten fixing screws. Check levers are horizontal and in line with the latch. Then firmly tighten fixing screws.</p>	<p>Pass trim over lever. Push trim to secure.</p>	<p>PRIVACY SET ONLY On the exterior side of door align emergency access holes on trim and furniture.</p>	<p>PRIVACY SET ONLY Screw in the privacy button on the interior side of door through hole in trim.</p>	<p>PRIVACY SET ONLY Depressing the privacy button will lock the (exterior) outside lever.</p>																
	<p>Tool Supplied</p>	<p>HAND OF DOOR ACCORDING TO ENGLISH PRACTICE</p> <table border="1"> <thead> <tr> <th colspan="2">DOOR OPENING IN</th> <th colspan="2">DOOR OPENING OUT</th> </tr> </thead> <tbody> <tr> <td>RIGHT HAND KIT</td> <td>INSIDE</td> <td>RIGHT HAND KIT</td> <td>INSIDE</td> </tr> <tr> <td></td> <td>LEFT HAND KIT</td> <td></td> <td>LEFT HAND KIT</td> </tr> <tr> <td></td> <td>OUTSIDE</td> <td></td> <td>OUTSIDE</td> </tr> </tbody> </table>		DOOR OPENING IN		DOOR OPENING OUT		RIGHT HAND KIT	INSIDE	RIGHT HAND KIT	INSIDE		LEFT HAND KIT		LEFT HAND KIT		OUTSIDE		OUTSIDE	<p>* FOR OUTWARD OPENING DOORS REFER TO STEP 7 & 8.</p>
DOOR OPENING IN		DOOR OPENING OUT																		
RIGHT HAND KIT	INSIDE	RIGHT HAND KIT	INSIDE																	
	LEFT HAND KIT		LEFT HAND KIT																	
	OUTSIDE		OUTSIDE																	
<p>PRIVACY SET ONLY Rotate (interior) inside lever to release privacy lock.</p>	<p>PRIVACY SET ONLY Insert and push pointed tool supplied to gain access from the (exterior) outside when the privacy button is engaged.</p>	<p>Cut mounting screws to measured door thickness plus 13mm.</p> <p>Cut length</p>																		

Strike preparation and installation (steps 22 - 27)

		<p>Door stop</p>	<p>30 mm</p>	<p>Striker Box Striker</p>
<p>Partially close door. Mark centre of latch bolt. Mark horizontal line along the inside face of the door jamb.</p>	<p>Measure the door thickness and halve it.</p>	<p>From the door stop along the horizontal line, measure and mark a vertical line at half the door thickness.</p>	<p>At this point drill 25mm hole, 13mm deep into the door jamb. Mark 30mm x 25mm box. Then chisel out jamb to the same depth for striker box.</p>	<p>Striker and striker box to be fitted into door jamb.</p>
<p>Align strike plate centrally and vertically over this box hole. Mark around plate. Chisel out jamb to allow strike plate & box to sit flush.</p>	<p>Drill 2x 2mm pilot holes and affix screws provided.</p>			

