


4. Releasing the Panel

(a) To release the panel: push locking lever to open position; lift the panel and slide the bracket away from the bolt hanger.

Note that the locking lever will automatically return to the locked position.

Do not use the bracket if the locking lever fails to

return to the locked position.








5. System Overview

End elevation of 120F track, 57JNP hanger, panel and 101N guide option.

Alternative track profiles and guide options available.



Care and Maintenance

General

Inspect all fixing bolts for tightness every six months, including those securing brackets. Tighten if necessary. Routinely check for wear and if excessively worn, the part should be replaced.

To help prevent surface corrosion, wash regularly with soap or mild detergent and warm water followed by rinsing with clean cold water and wipe dry.

Keep track free from obstruction and excessive dirt or water. Visible surfaces should be cleaned using a damp cloth and mild detergent, then wiped dry.

All hangers are fitted with lubricated ball-bearings, requiring no greasing. If doors 'settle' and door clearance is dreed causing friction, raise the door by the hanger adjustment hus. Wash as per the above recommendation and apply a light application of corrosion preventative to all surfaces, using a dry cloth to remove excess.

Guide roller and guide channel must be kept clear and free of obstructions. Wash as per the above recommendation and apply a light application of corrosion preventative to all surfaces, using a dry cloth to remove excess.

Allegion (New Zealand) Limited Freephone: 0800 477 869 Email: nzinfo@allegion.com www.allegion.co.nz



57JNP 19 January, 2021

CE2113 HL-092 (57JNP) 70克A4双面 |