


Quick Run 120: Hanger 58JNP for Recessed Installation



Pack Contents:


- 1. 2 x Hanger and Bolt
- 2. 2 x Mounting brackets
- 3. 4 x Fixing screws



1. Panel Preparation

(a) Use bracket as template to mark the hole position on panel.

Make sure the 2 brackets are in the same









(b) Route 12mm recessed slot (timber only) and pre-drill pilot holes for 10G screws.



(c) Fix bracket with mounting screw provided.



(d) Make sure the arrow on the locking lever points to



2. Hardware Installation

(a) Insert hanger with bolt into the track.



(b) If using 120CS clip stops: please ensure correct orientation of hanger to engage the 120CS




3. Attach Panel to Hanger


(a) Carefully lift the door panel with brackets, lining up the opening of the bracket with the bolt on hangers



(b) Use the spanner to turn the locking lever 90 degrees clockwise so the arrow points to the lock symbol.



(c) Adjust the height using the spanner provided. Clockwise will lower the panel, and anti-clockwise will raise the panel.




4. Releasing the Panel

(a) To release the panel: support the panel and turn the locking lever anti-clockwise to the released position and then lower the panel.





(b) Make sure to turn the locking lever to installation position after the panel is removed.



5. System Overview

End elevation of 120F track, 58JNP hanger, panel and 101N guide option.





Care and Maintenance

General

Inspect all fixing bolts for tightness every six months, including those securing brackets. Tighten if necessary. Routinely check for wear and if excessively worn, the part should be replaced.

To help prevent surface corrosion, wash regularly with soap or mild detergent and warm water followed by rinsing with clean cold water and wipe dry.

All hangers are fitted with lubricated ball-bearings, requiring no greasing. If doors 'settle' and door clearance is reduced causing friction, raise the door by the hanger adjustment nuts. Wash as per the above recommendation and apply a light application of corrosic preventative to all surfaces, using a dry cloth to remove excess.

Guide roller and guide channel must be kept clear and free of obstructions. Wash as per the above recommendation and apply a light application of corrosion preventative to all surfaces, using a dry cloth to remove excess.

Allegion (New Zealand) Limited Freephone: 0800 477 869 Email: nzinfo@allegion.com www.allegion.co.nz



58JNP 19 January, 2021

CE2115 HL-093 (58JNP) 70克A4双面