

Installation Instructions


454 Night Latch


Instructions


- 1. Choose the desired height on the door for the night latch, and drill according to template below
- 2. Determine whether the lock is required for open-in or open-out, and reverse the latch if needed (see below)
- 3. Secure the night latch to the door
- 4. Apply strike to the door jamb lower than the centreline, leaving 2mm for any door sag


Reversing latch

- 1. Undo the screw to remove the backing plate
- 2. Remove the circlip under the latch, allowing the latch to be removed from the body
- 3. Rotate latch and replace circlip
- 4. Replace backing plate










Template



Allegion (Australia) Pty Ltd Phone 1800 098 094 www.allegion.com.au Allegion (New Zealand) Limited Phone 0800 477 869 www.allegion.co.nz

