


Cylinders

ASSA ABLOY offers a complete range of quality cylinders. There are a number of cylinder types available, each offering a range of functional and security-oriented features.

Features:

- Can be keyed alike to other ASSA ABLOY CYL4™ cylinders for one key convenience
- Construction key and master key systems are available upon request
- The Oval, Euro, Rim, and Key N Knob series are C4 compatible and available in 5 or 6-pin options
- Euro Cylinder Note: P3000E Emergency type double cylinder assemblies are MC35 Securiturn™ compatible



Key Compatible Cylinder Types:


• C4 Pin Cylinder

- P3000 Euro Cylinder Series
- MC570 Oval Cylinder Series
- MC17 Rim Cylinder Series
- MC2600 Key N Knob Cylinder Series
- 180250 Albany Sliding Door Cylinder

• C4 Wafer Cylinder

- CYL4 Wafer Cylinder


E Type Cylinder




EURO "E" TYPE DOUBLE CYLINDER

PART NUMBER	FINISH	NO. OF PINS	A	B	COMMENT / DESCRIPTION
P33016E	S/CHROME	5	62	32	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33022E	S/CHROME	5	31	31	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33022ESC	S/CHROME	5	31	31	DOUBLE KEY, ESCAPE FUNCTION, INCLUDES MC35 SECURITURN
P33040E	S/CHROME	5	40	40	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33052E	S/CHROME	5	35	53	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33235E	S/CHROME	5	38	38	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33260E	S/CHROME	5	33	48	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33274E	S/CHROME	5 / 3	51	21	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33275E	S/CHROME	3	21	21	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33276E	S/CHROME	5	34	34	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33276EB	BLACK	5	34	34	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33280E	S/CHROME	3	24	24	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33285E	S/CHROME	5	85	30	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33300E	S/CHROME	5	37.5	47.5	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33302E	S/CHROME	5	31	47.5	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE
P33303E	S/CHROME	5	31	37.5	DOUBLE KEY, ESCAPE FUNCTION, SUITABLE FOR MC35 SECURITURN USE

Half Cylinder



Full Cylinder



EURO CYLINDERS - FIXED CAM

PART NUMBER	FINISH	NO. OF PINS	A	B	COMMENT / DESCRIPTION
P33017	S/CHROME	5	62	32	KEY & TURN KNOB, OFFSET
P33021	S/CHROME	5	45	45	DOUBLE KEY, J001
P33029	POL BRASS	5	31	31	KEY & TURN KNOB
P33032	POL BRASS	5	31	31	KEY & TURN KNOB
P33033	POL BRASS	5	31	31	DOUBLE KEY
P33034	S/CHROME	5	31	31	KEY & TURN KNOB
P33034B	BLACK	5	31	31	KEY & TURN KNOB
P33034KA	S/CHROME	5	31	31	KEY & TURN KNOB, KEYED ALIKE
P33035	S/CHROME	5	31	31	DOUBLE KEY
P33035KA	S/CHROME	5	31	31	DOUBLE KEY, KEYED ALIKE
P33041	S/CHROME	5	40	40	KEY & TURN KNOB
P33042	S/CHROME	5	10	40	HALF CYLINDER, KEY
P33043	S/CHROME	n/a	10	40	HALF CYLINDER, TURN KNOB
P33045	S/CHROME	5	10	31	HALF CYLINDER, KEY
P33046	S/CHROME	6	35	35	DOUBLE KEY, GRUB SCREW TOP PIN CLOSURE
P33046LP	S/CHROME	6	35	35	DOUBLE KEY, LESS PLUG
P33047	S/CHROME	6	35	35	KEY & TURN KNOB, GRUB SCREW TOP PIN CLOSURE
P33047K007	S/CHROME	6	35	35	KEY & TURN KNOB, K007
P33047LP	S/CHROME	6	35	35	KEY & TURN KNOB, LESS PLUG
P33048	POL BRASS	5	10	31	HALF CYLINDER, KEY
P33053	S/CHROME	5	10	35	HALF CYLINDER, KEY
P33054	S/CHROME	5	10	53	HALF CYLINDER, KEY
P33055	S/CHROME	5	31	37.5	KEY & TURN KNOB
P33056	S/CHROME	5	37.5	31	KEY & TURN KNOB
P33058	S/CHROME	5	47.5	31	KEY & TURN KNOB
P33059	S/CHROME	5	35	53	KEY & TURN KNOB
P33060	S/CHROME	5	53	35	KEY & TURN KNOB
P33062	S/CHROME	n/a	10	53	HALF CYLINDER, TURN KNOB
P33065	S/CHROME	5	31	47.5	KEY & TURN KNOB
P33066	S/CHROME	4	10	25.5	HALF CYLINDER, KEY, J81-J90
P33067	POL BRASS	4	10	25.5	HALF CYLINDER, KEY
P33071	POL BRASS	6	35	35	KEY & TURN KNOB
P33072	POL BRASS	6	35	35	DOUBLE KEY
P33073	S/CHROME	5	41	59	KEY & TURN KNOB
P33074	S/CHROME	5	59	41	KEY & TURN KNOB
P33075	S/CHROME	6	47.5	31	KEY & TURN KNOB
P33092	S/CHROME	n/a	10	31	HALF CYLINDER, TURN KNOB
P33092B	BLACK	n/a	10	31	HALF CYLINDER, TURN KNOB
P33093	POL BRASS	n/a	10	31	HALF CYLINDER, TURN KNOB
P33230	POL BRASS	n/a	10	47.5	HALF CYLINDER, TURN KNOB
P33231	S/CHROME	5	10	47.5	HALF CYLINDER, TURN KNOB

P33232	POL BRASS	5	37.5	37.5	KEY & TURN KNOB
P33233	POL BRASS	5	37.5	37.5	DOUBLE KEY
P33234	S/CHROME	5	37.5	37.5	KEY & TURN KNOB
P33234B	BLACK	5	37.5	37.5	KEY & TURN KNOB
P33235	S/CHROME	5	37.5	37.5	DOUBLE KEY
P33245	S/CHROME	5	10	37.5	HALF CYLINDER, KEY
P33261	S/CHROME	5	32.5	47.5	KEY & TURN KNOB, OFFSET
P33262	POL BRASS	5	32.5	47.5	DOUBLE KEY, OFFSET
P33263	POL BRASS	5	32.5	47.5	KEY & TURN KNOB, OFFSET
P33264	S/CHROME	5	10	47.5	HALF CYLINDER, KEY
P33265	POL BRASS	5	10	47.5	HALF CYLINDER, KEY
P33270	S/CHROME	5	45	45	KEY & TURN KNOB
P33277	S/CHROME	5	34	34	KEY & TURN KNOB
P33277B	BLACK	5	34	34	KEY & TURN KNOB
P33278	S/CHROME	n/a	10	34	HALF CYLINDER, TURN KNOB
P33278B	BLACK	n/a	10	34	HALF CYLINDER, TURN KNOB
P33279	S/CHROME	5	10	34	HALF CYLINDER, KEY
P33292	S/CHROME	n/a	10	37.5	HALF CYLINDER, TURN KNOB
P33292B	BLACK	n/a	10	38	HALF CYLINDER, TURN KNOB
P33293	S/CHROME	5	26	38	DOUBLE KEY
P33294	S/CHROME	5	48	33	KEY & TURN KNOB
P33297	S/CHROME	5	10	31	HALF CYLINDER, KEY
P33298	S/CHROME	5	10	47.5	HALF CYLINDER, KEY
P33299	S/CHROME	5	10	37.5	HALF CYLINDER, KEY
PQ16101	S/CHROME	n/a	10	24	HALF CYLINDER, TURN KNOB
PQ16102	S/CHROME	5	60	45	DOUBLE KEY, OFFSET
PQ16103	S/CHROME	3	24	24	KEY & TURN KNOB

EURO CYLINDERS - FLOATING/LAZY CAM

PART NUMBER	FINISH	NO. OF PINS	A	B	COMMENTS / DESCRIPTION
P33119	S/CHROME	5	37.5	37.5	DOUBLE KEY, 143° LOST MOTION CAM
P33097	S/CHROME	5	31	31	DOUBLE KEY, 143° LOST MOTION CAM 180250