



Schlage **Sense**™

Showroom Setup Guide

Pairing the lock for the **primary user**:

Using the **Schlage Sense**[™] Smart Deadbolt with Apple HomeKit[™] requires an iPhone[®], iPad[®] or iPod touch[®] with iOS 8.4 or later. The following instructions are written for users with iOS 9 or later. You must also be logged into your iCloud account and have your iCloud keychain enabled.

1

First decide who will be the primary user. The primary user will be in charge of adding all future users to the **Schlage Sense**[™] deadbolt. Next, download and launch the **Schlage Sense**[™] app from Apple's App Store. Make sure your device's Bluetooth[®] is turned on before you proceed to step two.



3

Tap Add New Lock

on the app's home screen.

Follow the on-screen instructions to select or create a home.

The app will activate your phone's camera and ask you to scan an **8-digit HomeKit**™ **setup code**, which can be found on the User Guide or on the lock itself.





Now it's time to name your lock. Fill in the suggested fields on screen.

Example

Siri Nickname: Front Door Access Code: 1234 Name Your Access Code: Admin

(Note: the name of the code should correspond with its user)



Lastly, if you are a first-time user, you will be prompted to take a guided tour—take it to explore all of the features the **Schlage Sense**[™] Smart Deadbolt has to offer.

Giving access to **additional users**:

To add additional users to the **Schlage Sense**[™] Smart Deadbolt, you'll need access to the primary user's iPhone[®], iPad[®] and iPod touch[®]. An invited user does not have sufficient privileges to complete these steps. If the primary user is unavailable, the lock will need to be factory reset, erasing all previously added users.

2

If you are the primary Schlage Sense[™] deadbolt user, exit the Schlage Sense[™] app and launch the Apple "Settings" app, instead. Once inside Settings, scroll down and select "HomeKit."



(Note: make sure you are in Bluetooth® range of the Schlage Sense[™] deadbolt before you proceed)

From the HomeKit[™] menu, select the home you wish to add

your new user to and tap Invite People

In the space provided, enter the iCloud account/email 3 address of the user you wish to add.

> (Note: if the new user does not know their iCloud account information visit icloud.com and follow the "forgot Apple ID" link.)

Once the new user accepts their invitation, they will be 4 able to use Siri® to lock and unlock the door. For full demonstration abilities, the user will need to download the Schlage Sense[™] app.

owned by Bluetooth SIG, Inc. and any use of such marks by Schlage Lock Company, LLC is under license.

Demonstrating Schlage **Sense**[™] Smart Deadbolt's advanced features

At this point, your lock is set up and ready to go! From here, explore any of the features below in any order. This section is simply meant to help you discover all that the **Schlage Sense**[™] deadbolt can do.

Welcome!

Once you've been made a HomeKit[™] user, you can demonstrate how to lock and unlock the **Schlage Sense**[™] Smart Deadbolt by tapping the lock on the app's home screen.

Talk to unlock with Siri®

To test out everything the **Schlage Sense**[™] deadbolt is capable of, start by talking to Siri[®]. Try asking Siri[®] to "lock my front door" or "unlock my front door." You can also say, "is my front door locked?" (Note: If you've named your lock something other than "front door," be sure to use the name you've given instead.)

Adding, scheduling and sharing codes

Try adding a new code by tapping the People icon in the lower right corner. Next, tap the plus sign and follow the on-screen instructions. You can schedule individual codes that work all the time or only during certain pre-determined times. Once you've selected when your new code can be used, tap the back button to complete the process. (Note: access codes can be quickly shared from the app via text/email)

Remember: adding a new code is the not the same as adding a new authorized user. To add authorized users, see page 2.

Advanced technology

Tap the Settings icon in the lower left corner of the app's home screen to explore the **Schlage Sense**[™] lock's advanced features, including its built-in alarm and auto-locking abilities.

Monitor activity

Stay up-to-date on who's coming-and-going by tapping the text at the bottom of the home screen in order to view all your **Schlage Sense**[™] activity.