

Warranty

The Schlage Encoder (BZ200) has a one year warranty.

Our goods come with guarantees that cannot be excluded under the local consumer law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

PDSC0056

Disclaimer

We continuously optimise products as new technologies and features are developed. For this reason, we reserve the right to make alterations to the products without prior notice.



ALLEGION

www.allegion.com.au
www.allegion.co.nz



Encoder (BZ200)

Quick Start Guide

Compatible with Schlage Omnia
and Schlage eGO Smart Locks



Schlage Encoder (BZ200)

Model :	Schlage Encoder (BZ200)
Dimensions :	70mm x 70mm x 26mm
Power interface :	Type-C USB
Power input :	5V/500mA
Radio frequency :	13.56Mhz
Support card type :	MiFare S50

Light/sound status



Light:


- Green light indicates: Encoder mode
- Blue light indicates: Reader mode

Sound:

- 🔊 One short beep indicates successful operation

Steps:

- 1 Connect the USB cable with PC



- 2 Plug the USB into the Encoder



- 3 Follow the instructions of the software to use the Encoder